




L-200

PARTS BREAKDOWN

PAGE 1/2

LIGHT HEAD
COMPONENTS ON
PAGE 2






L-200

PARTS BREAKDOWN

PAGE 2/2



#	Item No.	Description
1	PA-L5043	3/8-16 UNC x 2-1/2L Hex Bolt
2	PA-L5041	3/8-inch Spring Washer
3	PA-L5000	Light Head Assembly (incl. cord and U-Bracket)
4	PA-L5007	T-Handle Knob, T-Bar (L-200)
5	PA-L5036	3/8-16 UNC Nylon Nut
6	PA-L5003	3-Section Telescoping Mast Assembly
7	PA-L5005	Wheel
8	PA-L5034	5/8-11 UNC Nylon Nut
9	PA-L5038	5/8-inch Flat Washer
10	PA-L5042	M8 x P1.25 x 50L Hex Bolt
11	PA-L5019	Brake Rod
12	PA-L5013	Foot
13	PA-L5006	Power Cord, L200
14	PA-L5011	Lower Mast Clamp with Knob
15	PA-L5012	Upper Mast Clamp with Knob
16	PA-L5040	3/8-inch Flat Washer
17	PA-L5004	T-Bar, L200

#	Item No.	Description
18	PA-L5009	Power Supply
19	PA-L5001	Grill
20	PA-L5049	Grill Mounting Screw
21	PA-L5033	Plastic Cord Clip
22	PA-L5048	Screw
23	PA-L5002	U-Bracket
24	PA-L5027	Light Head Side Mounting Bracket
25	PA-L5029	Light Head Cable with Connector
26	PA-L5008	T-Handle Knob
27	PA-L5032	Strain Relief
28	PA-L5031	On/Off Switch
29	PA-L5028	Power Supply Mounting Cover
30	PA-L5010	Cart Base with Axle, L200