


patron®

L-400

PARTS BREAKDOWN

PAGE 1/2


LIGHT HEAD
COMPONENTS ON
PAGE 2





L-400

PARTS BREAKDOWN PAGE 2/2



#	Item No.	Description
1	PA-L5041	3/8-inch Spring Washer
2	PA-L5000	Light Head Assembly
3	PA-L5017	T-Bar
4	PA-L5040	3/8-inch Flat Washer
5	PA-L5036	3/8-16 UNC Nylon Nut
6	PA-L5015	Mast Assembly with Winch
7	PA-L5018	Fixed Plate
8	PA-L5035	1/2-13 UNC Nylon Nut
9	PA-L5039	1/2-inch Flat Washer
10	PA-L5038	5/8-inch Flat Washer
11	PA-L5045	Threaded Knob for Brake
12	PA-L5019	Brake Rod
13	PA-L5005	Wheel
14	PA-L5008	T-Handle Knob
15	PA-L5021	Foot Insert
16	PA-L5016	Cart Frame
17	PA-L5022	Electrical Box
18	PA-L5024	Power Cable & Plug

#	Item No.	Description
19	PA-L5037	M5 x 0.8 Nylon Nut
20	PA-L5023	Socket
21	PA-L5047	M5 x P0.8 x 10L Dishhead Screw
22	PA-L5046	Tensioner
23	PA-L5020	Carabiner
24	PA-L5025	Y-Shaped Cable
25	PA-L5043	3/8-16 UNC x 2-1/2L Hex Bolt
26	PA-L5031	On/Off Switch
27	PA-L5001	Grill
28	PA-L5049	Grill Mounting Screw
29	PA-L5033	Plastic Cord Clip
30	PA-L5048	Screw
31	PA-L5002	U-Bracket
32	PA-L5029	Light Head Cable with Connector
33	PA-L5032	Strain Relief
34	PA-L5009	Power Supply
35	PA-L5027	Light Head Side Mounting Bracket
36	PA-L5028	Power Supply Mounting Cover